

# REPLACEMENT SHEET




FIG. 3

## REPLACEMENT SHEET

### UTILIZATION STATE MANAGEMENT TABLE

| PORT ID | SLOT ID | SIZE | TYPE | STARTING DATE OF OPERATION | OPERATION STATE | DEVICE ID |
|---------|---------|------|------|----------------------------|-----------------|-----------|
| 001     | A       | 20GB | HI-1 | —                          | NOT USED        | —         |
| 002     | B       | 50GB | IM-1 | 2001/01/05                 | MOUNTING        | I5542     |
| 003     | C       | 50GB | SG-1 | 2001/01/05                 | MOUNTING        | F1041     |
| 004     | D       | 20GB | HI-1 | 2001/01/05                 | MOUNTING        | I3314     |
| 005     | E       | 20GB | HI-1 | —                          | NOT USED        | —         |
| 006     | F       | 20GB | HI-1 | —                          | NOT USED        | —         |
| 007     | G       | 50GB | QM10 | —                          | NOT USED        | —         |
| 008     | H       | 50GB | QM10 | —                          | NOT USED        | —         |
| 009     | I       | 50GB | QM10 | —                          | NOT USED        | —         |
| 010     | J       | 50GB | HI-2 | —                          | NOT USED        | —         |
| 011     | K       | 50GB | HI-2 | —                          | NOT USED        | —         |
| 012     | L       | 50GB | HI-2 | —                          | NOT USED        | —         |
| •       | •       | •    | •    | •                          | •               | •         |
| •       | •       | •    | •    | •                          | •               | •         |
| •       | •       | •    | •    | •                          | •               | •         |
| •       | •       | •    | •    | •                          | •               | •         |

FIG. 6